

PUMA DVR-009n INSTRUCTIONS

Set Date and Time

1. **Slide switch to “OFF” position. Plug the DVR into your computer via the USB port. Then slide switch to “ON” position.**
2. Connect the PUMA DVR to the computer via a USB port.
3. Click the PUMA DVR Software - Date and Time Sync from the [pumarecorders.com](http://www.pumarecorders.com) web site.
<http://www.pumarecorders.com/support.htm>
4. Click-on the Run button in the File Download dialog box.
5. The PUMA DVR application will display the computer’s current date and time. Click the [**Transfer**] button to send the date and time of the computer to the PUMA DVR. A message box will appear shortly after confirming the syncing of the date and time.
6. Close the PUMA DVR application by clicking the red “X” button located at the upper right hand corner of the application window and then disconnect the PUMA DVR from the PC.

Recording

1. To turn on the camera, please slide the slide-switch to “ON”. The BLUE indicator light on the right illuminates this indicates that the recorder is ready for operation at video mode.
2. To start a Video Recording, press the rec/stop button on the top briefly. An indicator light on the right will flash BLUE. This indicates that the video record function is operating. The resolution of the video will be 640x480.
3. To stop recording, press the button on the top briefly. The indicator light on the right illuminates in BLUE.

Still Images

1. To turn on the still image function, press the mode button briefly. The indicator light on the left will turn Green and the BLUE indicator light turns off. Press the rec/stop button on the top briefly. The green indicator light will turn off and the BLUE indicator light flashes once. This indicates that it just created a still image with the resolution of 1280x960. After that, the green light turns on automatically again. To get more images, press the rec/stop button again.

Motion Detection

1. To turn on the Motion Detect Function, slide the switch to motion detect. Once it detects motion within 1.5 meters, it will signal the camera to start video recording. The BLUE light flashes every 10 seconds. The recording last 2 minutes and it saves the video file automatically. A new motion will signal the camera to record again.
2. Slide to switch to OFF if no further recording is needed.
3. Slide the switch to ON if you need to download the video files.

How to charge: connect the camera with the USB cable to a USB Port on the computer. The RED light turns on. Slide the switch to “ON”. The BLUE light will turn on too. When the charge is finished, the RED light will turn off.

Low Power: Is indicated when the green light flashes for 10 seconds.

Memory full: Is indicated when both BLUE light and the GREEN light are on.

Download Recordings: **Slide switch to “OFF” position. Plug the DVR into your computer via the USB port.** Then slide switch to “ON” position. Allow a few seconds for recorder to recognize the DVR. Browse to the USB connected device via My Computer and open the folder. Copy the recordings to your desired computer folder or storage location. Note: Do not attempt to play recordings from the DVR.

Rec/Stop

